

JVC D-ILA® Projector

**DLA-HD350 / DLA-HD750
DLA-HD550 / DLA-HD950 / DLA-HD990
DLA-X3 / DLA-X7 / DLA-X9
DLA-X30 / DLA-X70R / DLA-X90R**

**DLA-RS10 / DLA-RS20
DLA-RS15 / DLA-RS25 / DLA-RS35
DLA-RS40 / DLA-RS50 / DLA-RS60
DLA-RS45 / DLA-RS55 / DLA-RS65**

Infrared Remote Control Command Emulation (Long Hex Format)

2012 / Version 3.0

Page 1 of 37

3D Format - Cycles through all available 3D formats (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 214 (0xD6)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 003C 0014 02BD

3D Setting - Direct access to 3D Auto mode (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 219 (0xDB)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C
0014 003C 0014 0295

3D Setting - Direct access to 3D Side by Side mode (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 220 (0xDC)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C
0014 003C 0014 02BD

3D Setting - Direct access to 3D Top & Bottom mode (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 221 (0xDD)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C
0014 003C 0014 0295

3D Setting - Direct access to 3D Setting menu (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 213 (0xD5)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 003C 0014 02BD

Advanced – Direct access to Picture Adjust > Advanced menu

(HD550/950/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 115 (0x73)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C
0014 0014 0014 02BD

Anamorphic – Off (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Vertical Stretch – Off (HD350/750/950/990/RS10/20/25/35)

Device Code: 115 (0x73) Function: 36 (0x24)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 0336

Anamorphic – A (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Vertical Stretch – On (HD350/750/950/990/RS10/20/25/35)

Device Code: 115 (0x73) Function: 35 (0x23)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 030E

Anamorphic – B (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 43 (0x2B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 02E6

Anamorphic – Cycles through Off/A/B (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 197 (0xC5)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C
0014 003C 0014 02E6

Aspect – 16:9

Device Code: 115 (0x73) Function: 38 (0x26)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 030E

Aspect – 4:3

Device Code: 115 (0x73) Function: 37 (0x25)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 030E

Aspect – Zoom

Device Code: 115 (0x73) Function: 39 (0x27)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 02E6

Aspect (PC) – Auto (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 174 (0xAE)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 02BD

Aspect (PC) – Full (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 176 (0xB0)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 030E

Aspect (PC) – Just (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 175 (0xAF)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 0295

Aspect + (cycles through all available modes)

Device Code: 115 (0x73) Function: 119 (0x77)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C
0014 0014 0014 0295

Auto Align (PC input on HD750/950/990/X7/X9/X70/X90/RS20/25/35/50/60/55/65)

Device Code: 115 (0x73) Function: 19 (0x13)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 0014 0014 030E

Auto Lens Center (X3/X7/X9/X70/X90/RS50/60/45/55/65)
Device Code: 115 (0x73) Function: 201 (0xC9)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 003C 0014 02E6

Back (steps backwards through menus and removes any OSD messages)
Device Code: 115 (0x73) Function: 3 (0x03)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014
0014 0014 0014 0336

BNR (Block Noise Reduction) Off
Device Code: 115 (0x73) Function: 16 (0x10)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 0014 0014 035E

BNR (Block Noise Reduction) On
Device Code: 115 (0x73) Function: 15 (0x0F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014
0014 0014 0014 02E6

Bright Level – (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 163 (0xA3)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 02E6

Bright Level + (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 162 (0xA2)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 030E

Brightness –**Device Code: 115 (0x73) Function: 123 (0x7B)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 0295

Brightness +**Device Code: 115 (0x73) Function: 122 (0x7A)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 02BD

Brightness Adj. (Adjustment Bar On/Off toggle)**Device Code: 115 (0x73) Function: 9 (0x09)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014
0014 0014 0014 0336

CEC – Off**Device Code: 115 (0x73) Function: 87 (0x57)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 02BD

CEC – On**Device Code: 115 (0x73) Function: 86 (0x56)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 02E6

**Clear Motion Drive - Cycles through: Off/ Mode1/Mode 2/Mode 3/Mode 4/Inverse Telecine
(X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)****Device Code: 115 (0x73) Function: 138 (0x8A)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014
0014 003C 0014 030E

Clear Motion Drive – Off (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 71 (0x47)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 02E6

Clear Motion Drive – Mode 1 (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 206 (0xCE)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C
0014 003C 0014 02BD

Clear Motion Drive – Mode 2 (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 207 (0xCF)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C
0014 003C 0014 0295

Clear Motion Drive – Mode 3 (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 72 (0x48)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 0014 0014 0336

Clear Motion Drive – Mode 4 (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 73 (0x49)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 0014 0014 030E

Clear Motion Drive – Inverse Telecine (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 74 (0x4A)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 0014 0014 030E

Color -

Device Code: 115 (0x73) Function: 125 (0x7D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 0295

Color +

Device Code: 115 (0x73) Function: 124 (0x7C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 02BD

Color Adj. (Adjustment Bar On/Off toggle)

Device Code: 115 (0x73) Function: 21 (0x15)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014
0014 0014 0014 030E

Color Management – Off (HD750/950/990/X7/X9/X70/X90/RS20/25/35/50/60/55/65)

Device Code: 115 (0x73) Function: 96 (0x60)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C
0014 0014 0014 0336

Color Management – Custom 1 (HD750/950/990/X7/X9/X70/X90/RS20/25/35/50/60/55/65)

Device Code: 115 (0x73) Function: 97 (0x61)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C
0014 0014 0014 030E

Color Management – Custom 2 (HD750/950/990/X7/X9/X70/X90/RS20/25/35/50/60/55/65)

Device Code: 115 (0x73) Function: 98 (0x62)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C
0014 0014 0014 030E

Color Management – Custom 3 (HD750/950/990/X7/X9/X70/X90/RS20/25/35/50/60/55/65)

Device Code: 115 (0x73) Function: 99 (0x63)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 011014 0014 0014 0014 0014 0014 0014 003C 0014 003C
0014 0014 0014 02E6

**Color Management – Cycles through: Off/ Custom1/Custom2/Custom3
(X7/X9/X70/X90/RS50/60/55/65)**

Device Code: 115 (0x73) Function: 137 (0x89)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014
0014 003C 0014 030E

Color Profile – Cycles through all available Color Profiles (X7/X9/X79/X90/RS50/60/55/65)

Device Code: 115 (0x73) Function: 136 (0x88)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014
0014 003C 0014 0336

Color Space – Cycles through Standard/Wide1/Wide2 (X3/X30/RS40/RS45)

Device Code: 115 (0x73) Function: 205 (0xCD)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C
0014 003C 0014 02BD

Color Temp. – 5800K (HD350/550/750/950/990/RS10/15/20/25/35)

Device Code: 115 (0x73) Function: 78 (0x4E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C
0014 0014 0014 02E6

Color Temp. – 6500K

Device Code: 115 (0x73) Function: 79 (0x4F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C
0014 0014 0014 02BD

Color Temp. – 7500K (HD350/550/750/950/990/RS10/15/20/25/35)

Device Code: 115 (0x73) Function: 80 (0x50)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 0336

Color Temp. – 9300K (HD350/550/750/950/990/RS10/15/20/25/35)

Device Code: 115 (0x73) Function: 81 (0x51)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 030E

Color Temp. – Custom 1

Device Code: 115 (0x73) Function: 83 (0x53)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 02E6

Color Temp. – Custom 2

Device Code: 115 (0x73) Function: 84 (0x54)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 030E

Color Temp. – Custom 3

Device Code: 115 (0x73) Function: 85 (0x55)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 02E6

Color Temp. – High Bright (HD350/550/750/950/990/X3/X30/RS10/15/20/25/35/40/45)

Device Code: 115 (0x73) Function: 82 (0x52)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C
0014 0014 0014 030E

Color Temp. + (cycles through all options)

Device Code: 115 (0x73) Function: 118 (0x76)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C
0014 0014 0014 02BD

Color Temperature Gain Blue – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 145 (0x91)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 030E

Color Temperature Gain Blue + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 144 (0x90)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 0336

Color Temperature Gain Green – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 143 (0x8F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014
0014 003C 0014 02BD

Color Temperature Gain Green + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 142 (0x8E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014
0014 003C 0014 02E6

Color Temperature Gain Red – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 141 (0x8D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014
0014 003C 0014 02E6

Color Temperature Gain Red + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 140 (0x8C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014
0014 003C 0014 030E

Color Temperature Offset Blue – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 151 (0x97)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 02BD

Color Temperature Offset Blue + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 150 (0x96)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 02E6

Color Temperature Offset Green – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 149 (0x95)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 02E6

Color Temperature Offset Green + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 148 (0x94)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 030E

Color Temperature Offset Red – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 147 (0x93)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 02E6

Color Temperature Offset Red + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 146 (0x92)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 003C 0014 030E

Contrast –
Device Code: 115 (0x73) Function: 121 (0x79)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 02BD

Contrast +

Device Code: 115 (0x73) Function: 120 (0x78)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 02E6

Contrast Adj. (Adjustment Bar On/Off toggle)

Device Code: 115 (0x73) Function: 10 (0x0A)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014
0014 0014 0014 0336

CTI (Color Transient Improvement) – Off (HD350/550/750/950/990/RS10/15/20/25/35)

Device Code: 115 (0x73) Function: 92 (0x5C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C
0014 0014 0014 02E6

CTI (Color Transient Improvement) – Low (HD350/550/750/950/990/RS10/15/20/25/35)

Device Code: 115 (0x73) Function: 93 (0x5D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C
0014 0014 0014 02BD

CTI (Color Transient Improvement) – Middle (HD350/550/750/950/990/RS10/15/20/25/35)

Device Code: 115 (0x73) Function: 94 (0x5E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C
0014 0014 0014 02BD

CTI (Color Transient improvement) – High (HD350/550/750/950/990/RS10/15/20/25/35)

Device Code: 115 (0x73) Function: 95 (0x5F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C
0014 0014 0014 0295

Cursor Down ▼**Device Code: 115 (0x73) Function: 2 (0x02)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014
0014 0014 0014 035E

Cursor Left ◀**Device Code: 115 (0x73) Function: 54 (0x36)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 0014 0014 02E6

Cursor Right ▶**Device Code: 115 (0x73) Function: 52 (0x34)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 0014 0014 030E

Cursor Up ▲**Device Code: 115 (0x73) Function: 1 (0x01)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014
0014 0014 0014 035E

Dark Level – (X7/X9/X70/X90/RS50/60/55/65)**Device Code: 115 (0x73) Function: 165 (0xA5)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 02E6

Dark Level + (X7/X9/X70/X90/RS50/60/55/65)**Device Code: 115 (0x73) Function: 164 (0xA4)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 030E

Detail Enhance –

Device Code: 115 (0x73) Function: 18 (0x12)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 0014 0014 0336

Detail Enhance +

Device Code: 115 (0x73) Function: 17 (0x11)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014
0014 0014 0014 0336

Picture Tone Blue – (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)

Device Code: 115 (0x73) Function: 161 (0xA1)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 030E

Picture Tone Blue + (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)

Device Code: 115 (0x73) Function: 160 (0xA0)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 0336

Picture Tone Green – (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)

Device Code: 115 (0x73) Function: 159 (0x9F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014
0014 003C 0014 0295

Picture Tone Green + (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)

Device Code: 115 (0x73) Function: 158 (0x9E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014
0014 003C 0014 02BD

Picture Tone Red – (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)
Device Code: 115 (0x73) Function: 157 (0x9D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014
0014 003C 0014 02BD

Picture Tone Red + (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)
Device Code: 115 (0x73) Function: 156 (0x9C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014
0014 003C 0014 02E6

Picture Tone White – (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)
Device Code: 115 (0x73) Function: 155 (0x9B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014
0014 003C 0014 02BD

Picture Tone White + (X7/X9/RS50/60 – Film Mode Only) (X70/X90/RS55/65 - All Modes)
Device Code: 115 (0x73) Function: 154 (0x9A)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014
0014 003C 0014 02E6

Gamma – Normal
Device Code: 115 (0x73) Function: 56 (0x38)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 030E

Gamma – A
Device Code: 115 (0x73) Function: 57 (0x39)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 02E6

Gamma – B

Device Code: 115 (0x73) Function: 58 (0x3A)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 02E6

Gamma – C

Device Code: 115 (0x73) Function: 59 (0x3B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 02BD

Gamma – D (HD550/950/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 63 (0x3F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 0295

Gamma – Custom 1

Device Code: 115 (0x73) Function: 60 (0x3C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 02E6

Gamma – Custom 2

Device Code: 115 (0x73) Function: 61 (0x3D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 02BD

Gamma – Custom 3

Device Code: 115 (0x73) Function: 62 (0x3E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 0014 0014 02BD

Gamma + (cycles through all options)

Device Code: 115 (0x73) Function: 117 (0x75)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 02BD

Hide (On/Off toggle)

Device Code: 115 (0x73) Function: 29 (0x1D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014
0014 0014 0014 02E6

Hide – Off (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 209 (0xD1)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C
0014 003C 0014 02E6

Hide – On (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 208 (0xD0)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C
0014 003C 0014 030E

Horizontal Position – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 171 (0xAB)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 02BD

Horizontal Position + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 170 (0xAA)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 02E6

Information (displays Information tab of menu)

Device Code: 115 (0x73) Function: 116 (0x74)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C
0014 0014 0014 02E6

Input – Component

Device Code: 115 (0x73) Function: 77 (0x4D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C
0014 0014 0014 02E6

Input – HDMI-1

Device Code: 115 (0x73) Function: 112 (0x70)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C
0014 0014 0014 030E

Input – HDMI-2

Device Code: 115 (0x73) Function: 113 (0x71)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C
0014 0014 0014 02E6

Input – PC (HD750/950/990/X7/X9/X70/X90/RS20/25/35/50/60/55/65)

Device Code: 115 (0x73) Function: 70 (0x46)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 030E

Input – S-Video (HD350/550/750/950/990)

Device Code: 115 (0x73) Function: 76 (0x4C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 030E

Input – Video (HD350/550/750/950/990)
Device Code: 115 (0x73) Function: 75 (0x4B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 0014 0014 02E6

Input + (cycles through all inputs)
Device Code: 115 (0x73) Function: 8 (0x08)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014
0014 0014 0014 035E

ISF – Day (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 100 (0x64)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 0014 0014 030E

ISF – Night (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 101 (0x65)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 0014 0014 02E6

ISF – Off (HD950/990/X7/X9/X70/X90/RS25/35/50/60/55/65)
Device Code: 115 (0x73) Function: 90 (0x5A)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C
0014 0014 0014 02E6

ISF – On (HD950/990/X7/X9/X70/X90/RS25/35/50/60/55/65)
Device Code: 115 (0x73) Function: 91 (0x5B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C
0014 0014 0014 02BD

Keystone Correction Horizontal –
Device Code: 115 (0x73) Function: 65 (0x41)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 0336

Keystone Correction Horizontal +
Device Code: 115 (0x73) Function: 64 (0x40)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 035E

Keystone Correction Vertical –
Device Code: 115 (0x73) Function: 28 (0x1C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014
0014 0014 0014 030E

Keystone Correction Vertical +
Device Code: 115 (0x73) Function: 27 (0x1B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014
0014 0014 0014 02E6

Lens Aperture – 1 (HD350/HD550)
Device Code: 115 (0x73) Function: 40 (0x28)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 0336

Lens Aperture – 2 (HD350/HD550)
Device Code: 115 (0x73) Function: 41 (0x29)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 030E

Lens Aperture – 3 (HD350/HD550)

Device Code: 115 (0x73) Function: 42 (0x2A)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 030E

Lens Aperture – If Lens Aperture Gauge is not displayed – displays gauge. If Lens Aperture Gauge is already displayed – Lens Aperture is decreased (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 31 (0x1F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014
0014 0014 0014 02BD

Lens Aperture + If Lens Aperture Gauge is not displayed – displays gauge. If Lens Aperture Gauge is already displayed – Lens Aperture is increased (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 30 (0x1E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014
0014 0014 0014 02E6

Lens Aperture Adj. (HD350/750/950/990/RS10/20/25/35 - Adjustment Bar On/Off toggle)

(X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65 - Displays Adjustment Bar)

(HD550/RS15 - Cycles through all options)

Device Code: 115 (0x73) Function: 32 (0x20)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 035E

Lens Control (cycles through all options)

Device Code: 115 (0x73) Function: 48 (0x30)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014
0014 0014 0014 0336

Lens Focus –**Device Code: 115 (0x73) Function: 50 (0x32)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014
0014 0014 0014 030E

Lens Focus +**Device Code: 115 (0x73) Function: 49 (0x31)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014
0014 0014 0014 030E

**Lens Memory - Cycles through Lens Memory Pages: Select/Save/Name Edit
(X30/X70/X90/RS45/55/65)****Device Code: 115 (0x73) Function: 212 (0xD4)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 003C 0014 02E6

Lens Memory 1 (X30/X70/X90/RS45/55/65)**Device Code: 115 (0x73) Function: 216 (0xD8)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C
0014 003C 0014 02E6

Lens Memory 2 (X30/X70/X90/RS45/55/65)**Device Code: 115 (0x73) Function: 217 (0xD9)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C
0014 003C 0014 02BD

Lens Memory 3 (X30/X70/X90/RS45/55/65)**Device Code: 115 (0x73) Function: 218 (0xDA)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C
0014 003C 0014 02BD

Lens Shift – Down**Device Code: 115 (0x73) Function: 34 (0x22)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 0336

Lens Shift – Left**Device Code: 115 (0x73) Function: 68 (0x44)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 0336

Lens Shift – Right**Device Code: 115 (0x73) Function: 67 (0x43)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 030E

Lens Shift – Up**Device Code: 115 (0x73) Function: 33 (0x21)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 0336

Lens Zoom – In**Device Code: 115 (0x73) Function: 53 (0x35)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 0014 0014 02E6

Lens Zoom – Out**Device Code: 115 (0x73) Function: 55 (0x37)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 0014 0014 02BD

Mask Bottom – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)**Device Code: 115 (0x73) Function: 184 (0xB8)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 02E6

Mask Bottom + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)**Device Code: 115 (0x73) Function: 183 (0xB7)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 0295

Mask Left – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)**Device Code: 115 (0x73) Function: 178 (0xB2)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 02E6

Mask Left + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)**Device Code: 115 (0x73) Function: 177 (0xB1)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 02E6

Mask Right – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)**Device Code: 115 (0x73) Function: 180 (0xB4)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 02E6

Mask Right + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 179 (0xB3)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 02BD

Mask Top – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 182 (0xB6)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 02BD

Mask Top + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 181 (0xB5)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014
0014 003C 0014 02BD

Menu (On/Off toggle)
Device Code: 115 (0x73) Function: 46 (0x2E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 02E6

Menu Position (HD550/950/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 66 (0x42)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 0014 0014 0336

MNR (Mosquito Noise Reduction) –
Device Code: 115 (0x73) Function: 14 (0x0E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014
0014 0014 0014 030E

**MNR (Mosquito Noise Reduction) +
Device Code: 115 (0x73) Function: 13 (0x0D)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014
0014 0014 0014 030E

**NR (toggles display of RNR/MNR) (HD350/550/750/950/990/RS10/15/20/25/35)
Device Code: 115 (0x73) Function: 24 (0x18)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014
0014 0014 0014 0336

**OK (to accept currently selected option)
Device Code: 115 (0x73) Function: 47 (0x2F)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 02BD

**Phase (PC Input) – (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 169 (0xA9)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 02E6

**Phase (PC Input) + (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 168 (0xA8)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 030E

**Picture Adjust (HD550/750/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 114 (0x72)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C
0014 0014 0014 02E6

Picture Mode – 3D (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 135 (0x87)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014
0014 003C 0014 02E6

Picture Mode – Cinema 1 (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65 - Film Mode)
Device Code: 115 (0x73) Function: 105 (0x69)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 02E6

Picture Mode – Cinema 2 (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65 - Cinema Mode)
Device Code: 115 (0x73) Function: 104 (0x68)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 030E

Picture Mode – Cinema 3
(HD550/750/990/RS15/25/35) (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65 - Animation Mode)
Device Code: 115 (0x73) Function: 102 (0x66)

00010 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
00141 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 10014 0014 02E6

Picture Mode – Dynamic (HD350/550/750/950/990)
Device Code: 115 (0x73) Function: 107 (0x6B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 02BD

Picture Mode – Natural
Device Code: 115 (0x73) Function: 106 (0x6A)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 02E6

Picture Mode – Stage

Device Code: 115 (0x73) Function: 103 (0x67)

00010 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
00141 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 10014 0014 02BD

Picture Mode – THX (HD750/950/990/X7/X9/X70/X90/RS20/25/35/50/60/55/65)

Device Code: 115 (0x73) Function: 111 (0x6F)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 0295

Picture Mode – User 1

Device Code: 115 (0x73) Function: 108 (0x6C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 02E6

Picture Mode – User 2

Device Code: 115 (0x73) Function: 109 (0x6D)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 02BD

Picture Mode – User 3 (HD550/750/950/990/X3/X30/RS20/25/35/40/45)

Device Code: 115 (0x73) Function: 110 (0x6E)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C
0014 0014 0014 02BD

Picture Mode – User 4 (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 202 (0xCA)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 003C 0014 02E6

Picture Mode – User 5 (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 203 (0xCB)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 003C 0014 02BD

Pixel Shift – Horizontal Blue – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 190 (0xBE)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 0295

Pixel Shift – Horizontal Blue + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 189 (0xBD)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 0295

Pixel Shift – Horizontal Green – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 188 (0xBC)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 02BD

Pixel Shift – Horizontal Green + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 187 (0xBB)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 0295

Pixel Shift – Horizontal Red – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 186 (0xBA)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 02BD

Pixel Shift – Horizontal Red + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 185 (0xB9)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 02BD

Pixel Shift – Vertical Blue – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 196 (0xC4)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C
0014 003C 0014 030E

Pixel Shift – Vertical Blue + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 195 (0xC3)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 003C 0014 02E6

Pixel Shift – Vertical Green – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 194 (0xC2)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 003C 0014 030E

Pixel Shift – Vertical Green + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 193 (0xC1)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 003C 0014 030E

Pixel Shift – Vertical Red – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 192 (0xC0)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C
0014 003C 0014 0336

Pixel Shift – Vertical Red + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 191 (0xBF)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 0014
0014 003C 0014 026D

Power – Off (send twice with short delay between to switch off)
Device Code: 115 (0x73) Function: 6 (0x06)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014
0014 0014 0014 0336

Power – On
Device Code: 115 (0x73) Function: 5 (0x05)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014
0014 0014 0014 0336

RNR (Random Noise Reduction) –
Device Code: 115 (0x73) Function: 12 (0x0C)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014
0014 0014 0014 0336

RNR (Random Noise Reduction) +
Device Code: 115 (0x73) Function: 11 (0x0B)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014
0014 0014 0014 030E

Screen Adjust – Off (X3/X30/RS40/45)
Device Code: 115 (0x73) Function: 128 (0x80)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014
0014 003C 0014 035E

Screen Adjust – A (X3/X30/RS40/45)
Device Code: 115 (0x73) Function: 129 (0x81)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014 0014
0014 003C 0014 0336

Screen Adjust – B (X3/X30/RS40/45)**Device Code: 115 (0x73) Function: 130 (0x82)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014
0014 003C 0014 0336

Screen Adjust – C (X3/X30/RS40/45)**Device Code: 115 (0x73) Function: 131 (0x83)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014
0014 003C 0014 030E

Sharpness –**Device Code: 115 (0x73) Function: 127 (0x7F)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 026D

Sharpness +**Device Code: 115 (0x73) Function: 126 (0x7E)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C 0014 003C
0014 0014 0014 0295

Sharpness Adj. (Adjustment Bar On/Off toggle)**Device Code: 115 (0x73) Function: 20 (0x14)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014
0014 0014 0014 0336

Shutter – Off – Un-synchronises shutter with “Hide” function**(HD550/950/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)****Device Code: 115 (0x73) Function: 45 (0x2D)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 02E6

**Shutter – On – Synchronises shutter with “Hide” function
(HD550/950/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 44 (0x2C)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 0014 0014 030E

**Shutter – Open (HD550/950/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 26 (0x1A)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014
0014 0014 0014 030E

**Shutter – Close (HD550/950/990/X3/X7/X9/X30/X70/X90/RS15/25/35/40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 25 (0x19)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014
0014 0014 0014 030E

**Test Pattern (cycles through all patterns) (HD350/550/750/950/990/RS10/15/20/25/35)
Device Code: 115 (0x73) Function: 89 (0x59)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C
0014 0014 0014 02E6

**THX – Off (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 199 (0xC7)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 003C
0014 003C 0014 02BD

**THX – On (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 200 (0xC8)**

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C
0014 003C 0014 030E

THX – Bright (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 133 (0x85)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014
0014 003C 0014 030E

THX – Dark (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 134 (0x86)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014
0014 003C 0014 030E

Tint – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 153 (0x99)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014
0014 003C 0014 02E6

Tint + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)
Device Code: 115 (0x73) Function: 152 (0x98)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014
0014 003C 0014 030E

Tint Adj. (Adjustment Bar On/Off toggle)
Device Code: 115 (0x73) Function: 22 (0x16)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014
0014 0014 0014 030E

Tracking (PC Input) – (X7/X9/X70/X90/RS50/60/55/65)
Device Code: 115 (0x73) Function: 167 (0xA7)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 02BD

Tracking (PC Input) + (X7/X9/X70/X90/RS50/60/55/65)

Device Code: 115 (0x73) Function: 166 (0xA6)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014
0014 003C 0014 02E6

User - Cycles through User 1 - User 5 Picture Modes (X30/X70/X90/RS45/55/65)

Device Code: 115 (0x73) Function: 215 (0xD7)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C
0014 003C 0014 0295

Vertical Position – (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 173 (0xAD)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 02BD

Vertical Position + (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 172 (0xAC)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014
0014 003C 0014 02E6

Vertical Stretch – Off (HD350/550/750/950/990/RS10/15/20/25/35)

Anamorphic – Off (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 36 (0x24)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 0336

Vertical Stretch – On (HD350/550/750/950/990/RS10/15/20/25/35)

Anamorphic – A (X3/X7/X9/X30/X70/X90/RS40/50/60/45/55/65)

Device Code: 115 (0x73) Function: 35 (0x23)

0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 003C
0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 0014 0014 0014 003C 0014 0014
0014 0014 0014 030E

**JVC Projector Infrared Remote Control Command Emulation
(Long Hex Format)
Version 3.0 03/08/2012**

Dale McWilliams – JVC Consumer A/V Group

This document may be distributed freely, as long as the author and copyright information remain intact.

User assumes all risks associated with implementation and utilization of this information.
No warranties are expressed or implied regarding usability, functionality or compatibility with any specific control systems.

Contents are subject to change without notice, as this document may be updated from time to time.
Please email any corrections, suggestions or requests for more information to dmcwilliams@jvc.com.

© 2012 JVC